

(b) Regardless of the requirements in paragraph (a) of this section, you must not flare or vent gas over the volume approved in your Development Operations Coordination Document (DOCD) or your Development and Production Plan (DPP) submitted to BOEM.

(c) The Regional Supervisor may establish alternative approval procedures to cover situations when you cannot contact the BSEE office, such as during non-office hours.

(d) The Regional Supervisor may specify a volume limit, or a shorter time limit than specified elsewhere in this part, in order to prevent air quality degradation or loss of reserves.

(e) If you flare or vent gas without the required approval, or if the Regional Supervisor determines that you were negligent or could have avoided flaring or venting the gas, the hydrocarbons will be considered avoidably lost or wasted. You must pay royalties on the loss or waste, according to 30 CFR part 1202. You must value any gas or liquid hydrocarbons avoidably lost or wasted under the provisions of 30 CFR part 1206.

(f) Fugitive emissions from valves, fittings, flanges, pressure relief valves or similar components do not require approval under this subpart unless specifically required by the Regional Supervisor.

§250.1161 When may I flare or vent gas for extended periods of time?

You must request and receive approval from the Regional Supervisor to flare or vent gas for an extended period of time. The Regional Supervisor will specify the approved period of time, which will not exceed 1 year. The Regional Supervisor may deny your request if it does not ensure the conservation of natural resources or is not consistent with National interests relating to development and production of minerals of the OCS. The Regional Supervisor may approve your request for one of the following reasons:

(a) You initiated an action which, when completed, will eliminate flaring and venting; or

(b) You submit to the Regional Supervisor an evaluation supported by engineering, geologic, and economic data indicating that the oil and gas pro-

duced from the well(s) will not economically support the facilities necessary to sell the gas or to use the gas on or for the benefit of the lease.

§250.1162 When may I burn produced liquid hydrocarbons?

(a) You must request and receive approval from the Regional Supervisor to burn any produced liquid hydrocarbons. The Regional Supervisor may allow you to burn liquid hydrocarbons if you demonstrate that transporting them to market or re-injecting them is not technically feasible or poses a significant risk of harm to offshore personnel or the environment.

(b) If you burn liquid hydrocarbons without the required approval, or if the Regional Supervisor determines that you were negligent or could have avoided burning liquid hydrocarbons, the hydrocarbons will be considered avoidably lost or wasted. You must pay royalties on the loss or waste, according to 30 CFR part 1202. You must value any liquid hydrocarbons avoidably lost or wasted under the provisions of 30 CFR part 1206.

§250.1163 How must I measure gas flaring or venting volumes and liquid hydrocarbon burning volumes, and what records must I maintain?

(a) If your facility processes more than an average of 2,000 bopd during May 2010, you must install flare/vent meters within 180 days after May 2010. If your facility processes more than an average of 2,000 bopd during a calendar month after May 2010, you must install flare/vent meters within 120 days after the end of the month in which the average amount of oil processed exceeds 2,000 bopd.

(1) You must notify the Regional Supervisor when your facility begins to process more than an average of 2,000 bopd in a calendar month;

(2) The flare/vent meters must measure all flared and vented gas within 5 percent accuracy;

(3) You must calibrate the meters regularly, in accordance with the manufacturer's recommendation, or at least once every year, whichever is shorter; and